Editing the VTW

Use TONE EDIT or the [PARAM] buttons to edit the VTW.

ZOOM EDIT (WHEEL) screen

Tab
When using the [E1] knob to scroll and select, the parameters to set are shown on the right side.

<UTILITY>
Touch this to show the tone initialization menu.

TONE EDIT VTW ZOOM   ZONE2   Tone Wheel Organ   SAMPLE PAD   UTILITY

To PRO   MFX   Level 127

VTW
OVERDRIVE
ROTARY
MFX
MFX CTRL

8' 2⅔' 2' 1⅗' 1⅓' 1'
16' 5⅓' 8'

Harmonic bars
Drag the bars shown onscreen to edit the parameters. You can also use sliders 1–9 to do this.

ROTARY   OVERDRIVE   VIB & CHO   PERCUSSION
SLOW FAST   ON   OFF   ON   SLOW FAST
Brake   V3 C3   NORM SOFT   2ND 3RD
            C2   V2 C1 V1

Knobs [E2]–[E6]
The parameters in this area are assigned.
Press or turn the knobs to edit a parameter.